

Ocean Technology Systems

Installation of the SCU-BUD into the ScubaPro Full-Face Mask



1. Unscrew and remove the metal band that secures the mask's left accessory port cover, to which the lower mask strap is attached. Remove the accessory port cover.



2. Remove the mask strap from the accessory port cover. Remove the male buckle end from the strap, and set it aside. Install the mask strap into the buckle of the Buddy Phone[®] microphone module.



3. Install the Buddy Phone[®] microphone module into the mask's left accessory port.



4. Close the metal band around the opening of the accessory port and tighten the screw, so that the microphone module is securely attached.



5. Fully insert the upper left head strap of the mask into the strap retainer slot on the Buddy Phone® so that the Buddy Phone® will be positioned over the left ear.



6. Don the mask and assure the microphone is positioned as close to your lips as possible (less than 1/4 inch is best). The correct microphone position is important: If it is too far from your lips, communications will sound weak and distant.

7. Adjust the ScubaPro Buddy Phone® so the earphone is over your ear or as close to it as possible.



8. Secure the Buddy Phone® cable to the mask strap buckle with a tie wrap. The tie wrap should be just loose enough that the cable can move freely through it. Cut off all excess length of tie wrap.



A fully installed ScubaPro Buddy Phone®

Undersea Systems International, Inc. dba

Ocean Technology Systems

3133 W. Harvard Street • Santa Ana • California • 92704 • USA

Toll-Free (800) 550-1984 • Telephone (714) 754-7848 • Fax (714) 966-1639 • Email: ots@oceantechnologysystems.com

www.oceantechnologysystems.com

Installation Instructions

506106-000 (A)