

## *Ocean Technology Systems*

### **Installation of the Mic/Ear Assembly into the AGA Full Face Mask**

1. Remove the existing AGA cover plate by loosening the two thumb screws.



2. Insert the microphone portion into the port. The nickel microphone wires may need to be bent slightly to install. Tighten thumb screws (hand tight only).

3. Once the microphone is inside the port, carefully position the microphone within ¼" from the diver's lips. This will place the microphone at the left corner of the diver's lips. The Hot Mic is shown above, other microphones are available.

4. Remove the chin and temple straps on the full face mask.



5. Ensure the snap of the EHA-1 earphone holder is facing towards the front of the mask and the logo is upright.

6. Insert the AGA straps through the top and bottom slots of the EHA-1. Re-assemble the AGA straps into the mask.



7. The EP-2 earphones are directional. Ensure the soft side is facing toward the diver's ear.



8. Insert the earphones with the cable coming out below the snap. Secure the snap.



9. Loosely secure the cable to the buckle of the full face mask with the supplied tie wrap as shown. **CAUTION:** Be sure the tie wrap does not bind the cable so it can slide freely. Improper installation may cause the mask to leak.



10. The completed installation of the EMA-2 (911060-001) is shown above. **Safety Note:** When donning the mask, position the earphone holders as far back as possible to prevent them from binding in the strap buckles. Adjust the earphone holders into position after the mask has been properly tightened.

**Undersea Systems International, Inc. *dba***  
***Ocean Technology Systems***

**3133 West Harvard Street • Santa Ana • California • 92704 • USA**

Telephone (714) 754-7848 • Toll-Free (800) 550-1984 • Fax (714) 996-1639 • Email: [ots@oceantechnologysystems.com](mailto:ots@oceantechnologysystems.com)  
[www.oceantechnologysystems.com](http://www.oceantechnologysystems.com)